




**A
U
T
O
M
A
T
I
C
C
H
O
I
C
E**

**Transfer Shaft Bearing
Snap Ring Remover/Installer**



Part No. TOOL.68



**T
H
E
A
U
T
O
M
A
T
I
C
T
R
A
N
S
M
I
S
S
I
O
N
P
A
R
T
S
W
A
R
E
H
O
U
S
E**